

FITTING GUIDE FOR REAR SPRING

VWR 31ID00 VWR VW ID.3 Sport Springs

Thank you for choosing the RacingLine ID3 / Cupra Born Sport Lowering Springs . Please ensure the kit is correct for your application – see guide on website if in doubt. As this kit is critical for vehicle function, we strongly recommend that a professional with suitable experience performs the installation of this kit.

Remove the original rear springs by removing the shock absorber bolt and the wheel hub bolt. Then, remove the plastic spring seat on the suspension arm by pushing the plug out underneath the suspension arm.

Replace the rubber spring seat (originally supplied with the car) with part number 1EA 512 149 on to the top of the RacingLine Spring. Next use the RacingLine supplied rubber seat (Part number 1EA 512 149) on the bottom. The spring should fit securely in the rubber spring seats. Secure the rear suspension with the original bolts for the shock absorber and wheel hub.

